


Profile migration to Net ID


1. Please reboot the computer and log in to your CVM account with your CVM ID and password.




2. Once inside click the Zenworks icon on the bottom right side of your screen.




3. The Zenworks window will then open, now type "Profile migration profile" in the searchbox in the Zenworks window.



4. Click the icon and install the program, it will then start the migration process which averages 15 minutes. Click the ok button to continue.



5. Please close the ZENworks window by clicking the X in the top right hand corner of the ZENworks window



6. During this process you will get a powershell screen prompt asking for your NetID and password. Type it in and hit OK.




7. You will then immediately get another powershell screen prompt now asking for your CVM ID and password. Type it in and hit OK.



8. You will then see the profile migration status bar move during this process.



9. Your machine will then reboot after the migration and then you will be able to log in with your NetID@tamu.edu, hit ok and continue.



10. Once you have logged in with your NetID then the process will have been complete.

If for any reason your issue is not resolved please contact the CVM Helpdesk for further assistance by using the CVM Asset Tag Utility to create a ticket. See article below

<https://helpdesk.cvm.tamu.edu/servicedesk/selfhelp/kba/55>

If you have any issues with this knowledge base or article contact the CVM help Desk at 979 862 4554 or write to us: helpdesk@cvm.tamu.edu